

EN TECHNICAL DATASHEET


PRODUCT DATA

Reference: DELUXE POP UP

Description: Outdoor folding gazebo

Dimensions: 300x300x250-270 cm

Color: Anthracite




TECHNICAL SPECIFICATIONS

MATERIAL	Steel and 160 g/m ² polyester
UV PROTECTION	UV50 +
WATER RESISTANCE	Water-repellent
FIXINGS	Guy ropes and pegs
ACCESSORIES	Carry bag and refillable weights
URECOMENDED USE	Gardens, terraces, patios, and outdoor areas

ASSEMBLY AND USE

The assembly of the DELUXE POP UP tent is simple and can be done by one person. The structure unfolds on a stable surface until the central button clicks, confirming its full opening. The canopy is fixed using hook-and-loop fasteners and clips for an optimal hold. The height is adjustable in three positions (250, 260, and 270 cm). To ensure outdoor stability, it is essential to use the ropes, the eight pegs, and the included refillable weights for secure anchoring. To disassemble, pull the central button to release the structure. It is necessary to remove the canopy's fasteners before folding the frame and storing it in its carry bag.



MAINTENANCE

Periodically check the frame and fixing points to ensure they are in good condition. The canopy should be cleaned with water and mild soap, avoiding abrasive products. It is recommended to dry the fabric completely before storage to prevent mold. The gazebo should be stored in its carry bag in a dry, protected place, and should not be left permanently assembled or exposed to adverse weather conditions.